


PORTER-CABLE

RANDOM ORBIT POLISHER

WARNING: Electrical repairs should only be attempted by trained repairmen. Contact the nearest Porter-Cable Service Center or other competent repair center

7424



Ref. No.	Part No.	Description
1	872987**	Armature, Incl: Ref. 1B
1A	698153	Baffle
1B	811292**	Armature Fan
2	872988	Field , T1
	891211	Field , T2
3	690741	Brush, T1
	888386	Brush & Holder Assy., T2
3B	690742	Brush Holder, T1
4	694006	Switch
4A	694924	Dust Shield
4B	693971	VS Switch
5	872258	Cord
11	855284	Bearing
14	855219	Bearing
20	872991	Spindle & Bearing Assy.
22	698178	Grease Pluq, T1
31	872990**	Pinion
31A	872989	Gear & Shaft Assy.
52	888001	Motor Hsq. , Incl.: Ref 3, 119, 122
52B	698738	Mtr. Hsg. Cap
53	891106	Gear Hsq./Int. Plate , Incl.: Ref. 144
53A	699946**	Gear Housing Cover
91	874011	Counterweight
99	882187	Screw
100	699938	Plate-Gear
101	872502	Spacer
102	699925	Spacer
103	699924	Spacer
105	876651	Screw
107	872503	Spacer
109	698394	Tube-Insulating
110	695893	Washer-Fiber
111	849328	Spacer
112	694432	Bearing Mount
114	874502	Indicator Switch

Ref. No.	Part No.	Description
115	874525	Switch Button and Slide Pkq.,
117	694012	Screw
118	810716	Strain Relief
119	699998	Lead Assy., T1
	887666	Lead Assy., T2
120	861434	Cord Clamp
121	882185	Screw
122	854805	Screw, T1
	879298	Screw, T2
123	868775	Spring
124	690740	Brush Holder Base
125	699942	Vacuum Housing
126	845619	Screw
127	851584	Washer Thrust
128	884277	Eccentric Hsg, Incl: Ref. 132
129	874513**	Eccentric Washer
130	695936	Rubber Plug
131	874511**	Hex Screw
132	877817	Screw
140	699681	Aux. Handle
141	873140	Shim (As Required)
142	695185	Screw
143	847564**	Snap Ring
144	697029**	O-Ring
145	859359**	Washer (Balance)
146	850218	Spacer
*	54745	6" Polishing Pad
* n	874809**	Lubricant (5 1/2 oz.)
* n	875667**	Lubricant (5 lbs.)
*	48779	Spindle Wrench
* n	892163	Carrying Case
*	895251	Polishing Compound
*		Not Shown
**		See Service Notes

WASHER (REF.#145)


A flat washer may be used under the head of one or both counterweight screws (Ref. #132) to fine tune balance.

DISASSEMBLY


CAUTION: Disconnect tool from power source before servicing.

Service to the cord, switch, and brushes may be accomplished by removing the motor housing cap (Ref. #52B). Any service to the motor or gear case areas requires removal of the random orbit system and the gear housing cover, as follows:

1. Hold spindle with spindle wrench, while rotating pad counter-clockwise to remove.
2. Hold flats of eccentric housing (see Fig. 1) with pump pliers, while removing two counterweight screws.
3. Remove counterweight; pull spindle and bearing assembly out.
4. Hold flats of eccentric housing with pump pliers, while removing eccentric housing retaining screw and washer.
5. Pull eccentric housing off and remove spacer (Ref. #127).
6. Remove three retaining screws and eccentric housing cover (Ref. #125).
7. Insert the blade of a 3/16" wide, "flat" screwdriver at one pry point (see Fig. 2) and pry housing cover (Ref. 53A) outward and forward to release from gear housing. Repeat at the second pry point to release and remove cover.



SERVICE NOTES




ARMATURE/PINION/BEARING/INTERMEDIATE PLATE/FAN

The pinion gear (Ref. #31) is a press-fit to the armature shaft. Disassembly/assembly requires an arbor press and special fixtures (available from Porter-Cable Technical Service) to disassemble:

1. Support intermediate plate/armature assembly on 86759 bearing removal fixture (pinion end up). Press against the end of the armature shaft to drive the armature/pinion assembly out of the intermediate plate.
2. Wrap one shop towel around armature body and another around the fan to protect hands from sharp edges. Grasp body in one hand and fan in the other, twist fan to break bond (to insulating tube). The fan will be damaged and MUST be replaced.
3. Slide fan back toward armature coils. Position armature assembly to the 867759 bearing puller with pulley jaws positioned between the fan and the bearing. Use arbor press to drive armature out of bearing and pinion. The bearing will be damaged and MUST be replaced. Remove snap-ring and fan.

TO REASSEMBLE:

1. Apply super-glue to bore of new fan. Use special fixture (699921) to position fan on armature (length of fixture = distance from fan to end of shaft).
2. Install snap-ring (Ref. 143).
3. Coat intermediate plate bore with Loctite and assemble new bearing.



Use the special fixture (699921) to support the inner race of the bearing (and intermediate plate) while pressing the armature through the bearing until approximately $\frac{1}{4}$ " of shaft protrudes through bearing.

Remove from fixture. Place pinion spacer (Ref. 147) and pinion onto armature shaft. Press until end of pinion is flush with end of shaft.

WIRING DIAGRAMS