



Model No.	IBM Number
1506134	060 1506 134

1506 134

Shear 1506-134 (Cont'd)

POS. NO.	PART NO.	PCS/UNIT	DESCRIPTION	POS. NO.	PART NO.	PCS/UNIT	DESCRIPTION
25	2 605 500 054	1	Gear cover	69	2 600 224 009	2	Circlip
26	2 600 914 011	1	Needle bushing	70	2 915 011 009	1	Hexagon nut
27	2 605 806 316	1	Gear housing	71	1 603 481 001	1	Handle
28	2 916 650 011	1	Circlip	101	2 605 108 041	1	Crankshaft housing
29	1 900 900 274	1	Deep groove ball bearing	102	2 604 010 607	1	Armature, 115V
30	2 600 550 017	1	Disc spring	103	2 600 101 023	1	Shim, 0.03mm, as required
31	2 606 334 040	1	Ring gear	103.1	2 600 101 022	1	Shim, 0.02mm, as required
32	3 605 700 042	1	Intermediate flange	103.2	2 600 101 020	1	Shim, 0.05mm, as required
33	2 600 905 015	1	Deep groove ball bearing	104	2 600 150 004	1	Shim
34	2 916 660 008	1	Circlip	105	1 900 905 011	1	Deep-groove ball bearing
36	2 910 211 021	4	Self-tapping screw	106	2 604 220 428	1	Field, 115V
37	2 916 690 003	7	Spring lock washer	107	2 603 435 015	2	Recessed head screw
38	2 910 021 138	4	Fillister head screw	108	2 602 319 005	1	Adjusting slide
40	2 910 021 134	3	Fillister head screw	109	2 602 026 015	1	Switch handle
41	2 605 510 049	1	Chip deflector	110	2 601 328 034	1	Cover disc
42	3 600 328 029	1	Spacer sleeve	111	2 601 323 021	2	Brush holder
43	2 910 775 126	1	Flat-head screw	112	See pos. 801	2	Carbon brush set
45	2 910 141 290	1	Hex socket head cap screw	114	2 604 652 007	2	Spiral spring
46	2 603 400 011	1	Headless setscrew	115	2 604 460 022	1	Cord set
47	2 600 500 002	1	Plate washer	116	2 600 703 013	1	Grommet
48	2 600 108 002	1	Felt washer	117	2 601 035 001	1	Cable clip
49	2 600 400 008	1	Ring	118	2 910 211 019	2	Self tapping screw
50	2 916 080 908	2	Locking washer	119	2 910 211 005	4	Self tapping screw
51	1 600 100 611	2	Shim	120	2 607 200 093	1	On-off switch
52	1 903 201 020	20	Needle roller	121	2 603 410 001	4	Fillister head screw
53	2 606 316 095	2	Cylindrical gear	123—	2 604 448 034	2	Cable
54	2 603 105 021	2	Bearing pin	124	2 604 448 039	1	Cable
55	2 910 011 116	1	Fillister head screw	125	2 604 448 040	1	Cable
57	2 608 635 042	1	Lower blade	126	3 601 106 000	1	Nameplate blank
58	2 608 042 002	1	Blade holder	127	1 600 026 000	1	Intermediate piece
59	2 603 100 002	2	Straight pin	128	2 600 508 036	1	Housing cover
60	2 603 414 026	2	Hex socket head cap screw	129	2 910 601 421	1	Self tapping screw
61	2 608 635 065	1	Upper blade	130	2 601 110 243	1	Label
62	2 603 480 001	1	Adjusting screw	131	3 601 103 006	1	Label
63	2 603 070 008	1	Lifting rod	139	2 910 211 007	1	Self tapping screw
64	2 600 400 001	1	Bearing sleeve	200	1 900 452 012	2	Wire Barrel
65	2 603 100 003	1	Bearing pin	655A	2 607 970 001	1	Feeler gauge
66	2 602 001 001	1	Connecting rod	656A	1 907 950 003	1	Allen wrench
67	2 600 913 035	1	Needle roller cage	657A	1 907 950 006	1	Allen wrench
68	2 606 122 003	1	Eccentric shaft	801	2 604 320 908	1	Carbon brush set

-- = Not illustrated  
A = Accessory