



# REPLACEMENT PARTS

Ref.			Ref.		
No.	Part No.	Description	No.	Part No.	Description
2	900439	KNOB	48	1311035	STOP PIN
3	900400	PIN	49	1343767	PINION ASSY
4	900432	V-BELT	50	1311034	PIN
5	900303	PULLEY COVER	51	1311037	LOCK SCREW
6	1343740	SPEED CHART	52	1343770	DEPTH STOP
7	900415	DEC PLATE	54	900413	SCALE
8	1246002	SCREW-CHEESE HD	55	1343769	BALL
9	1343304	WASHER-RUBBER	56	1343768	HANDLE ASSY
10	1243407	RING-EXT RET	57	1246110	PIN-SPRING
11	920-04-020-5335	BEARING-BALL	58	900436	THUMB SCREW
12	1310046	SPACER	59	1246133	SCREW
13	1310044	SLEEVE	60	1310022	SLIDE ROD
14	1310048	PULLEY	61	1310021	SPRING
15	1310047	NUT	62	1246017	SCREW-HEX HD
16	1340719	CLAMP	63	1243526	WASHER-FLAT
17	1342455	SCREW-PAN HD	64	1345382	NUT-LOCK
18	1343785	CORD INSULATOR	65	900438	MOTOR PLATE
19	1310055	SCREW-HEX SOC SET	66	1246016	SCREW-HEX HD
20	1310054	PULLEY	69	900302	MOTOR
21	902-01-020-1227	NUT-JAM	70	1343784	MOTOR JUMPER
22	1310084	SPRING W/HSG.	71	1311072	POWER CORD
23	1310035	RETAINER	72	900433	RING
24	1343772	SPRING SEAT	73	1243321	SCREW-HEX SOC SET
25	900417	WARNING LABEL	74	900301	TABLE
27	1246133	SCREW-HEX SOC SET	75	1343716	SCREW-HEX HD
28	1243398	NUT-HEX	76	902-01-120-1034	NUT-HEX
29	1343774	SCREW-HEX SOC SET	77	1310013	THD. PIN
30	1320101	WASHER-EXT TOOTH	78	1343747	PIN
31	1310155	SCREW-CHEESE HD	79	1310017	HANDLE
32	1343778	SWITCH BOX	80	1310016	SCREW-DRIVE
33	1246001	SCREW-CHEESE HD	81	1343762	SCALE
34	1343783	SWITCH PLATE	82	1343786	WORM
35	1310547	SCREW-PAN HD	83	1343754	PINION
36	1343758	KEY	84	1344257	HANDLE ASSY
37	1343759	SWITCH	85	1246014	SCREW-HEX HD
38	900437	HEAD STOCK	86	1343735	RACK
39	1310064	RING-EXT RET	87	1343736	COLUMN W/FLANGE
40	1310039	WASHER-RUBBER	88	1246016	SCREW-HEX HD
41	1310041	BEARING-BALL	89	900300	BASE
42	1343775	QUILL	100	1311071	KEY
43	1343776	SPINDLE	103	1243569	NUT-HEX
44	1310049	CHUCK	104	1320102	WASHER-EXT TOOTH
45	1313104	CHUCK KEY 1/2"	105	1243501	SCREW-CHEESE HD
46	1310016	SCREW-DRIVE			
47	900435	POINTER			

---

## STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

*This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.*