



Ref.

No.	Part No.	Description
1	898877	Armature, T2
	883092	Armature, T1
1A	878948	Fan
2	898876	Field
3	874289	Brush & Spring
3B	865323	Brush Holder
3C	865321	Insulator
4	883498	Switch
5	867853	Cord
11	855284	Bearing
11A	883096	Bearing
15B	883095	Bearing
31A	879401	Gear
40D	880964	Recip. Shaft
52	874312	Motor Hsg.
57	892792	Handle Set
81	897774	Collar
100	695077	Bracket
101	690673	Tie
107	882703	Screw
108	897576	Insulator Boot
114	694432	Bearing Mount
121	882704	Screw
125	879421	Screw
130	879414	Intermediate Plate
138	879458	Plate
141	883097	Drive Shaft
142	803207	Washer
143	879411	Wobble Plate
147	802302	Retaining Ring
148	879429	Spacer
150	883213	Carrier Tube

Ref.

No.	Part No.	Description
153	882348	Felt Seal
158	879423	Front Hsg.
159	879457	Felt Seal
161	891672	Shoe
163	849235	Screw
165	879463	Screw
181	882189	Screw
187	879408	Screw
188	880952	Plug
190	853246	Retaining Ring
196	882255	Screw
197	879460	Spring
198	884696	Retainer Kit
199	879442	Clamp Pin
203	879459	Rubber Seal
206	846249	Wire Nut
216	843464	Strain Relief
217	48248	Wrench
219	879449**	O-Ring
235	879447	Plug
236	882187	Screw
237	801852	Felt Seal

ACCESSORIES: (Optional)

218	842323	Wrench Holder
230	875914	Lubricant, (5 1/2 oz.)
231	875667	Lubricant, (4 lbs.)
233	53672	Carrying Case

O-RING - REF. 219

Early units were produced with O-Ring 879449 Ref. 219 to help retain the Carrier Tube Ref. 150. It has been determined that the Carrier Tube Retaining Screws Ref. 187 provide more than adequate support and the O-Ring has been eliminated. When servicing early units you should discard the O-Ring Ref. 219 and reassemble the unit without it.