



Pos.	Part Number	Description {Qty}	F/C	Pos.	Part Number	Description {Qty}	F/C
1	2 605 104 501	Motor Housing Assy.	71	81	2 601 015 062	Seal	77
2	2 607 022 934	Motor w/Gear 9.6V w/pos. 2/10, 47	19	82	2 916 070 006	Washer {2}	65
2/10	2 604 413 012	Cable 118mm {2}	10	83	2 604 619 016	Spring	27
4	2 607 200 342	Switch VSR	17	84	1 903 230 406	Ball 3.5mm {2}	66
9	2 610 909 843	Label "3220"	9	85	2 600 400 032	Collar	92
20	2 610 909 842	Nameplate "Caution"	9	86	2 916 600 007	Spring Ring	89
27	1 900 900 224	Ball Bearing	56	87	2 601 099 061	Selector Lever	9
29	2 605 510 143	Housing Cover	70	89	2 605 801 019	Bushing	82
38	2 603 000 016	Drive Shaft	54	90	2 600 100 638	Washer	65
40	2 606 309 045	Spindle Gear	32	100	2 601 322 016	Clamping Spring	80
41	2 606 319 086	Intermediate Gear	31	102	2 601 329 041	Battery Retaining Clip	9
47	2 606 316 147	Pinion Gear	33	110	2 603 435 064	Screw {6}	89
56	1 903 230 010	Ball 5.5mm {2}	66	113	2 600 100 098	Washer	65
57	2 605 700 231	Intermediate Plate	38	114	2 608 040 072	Bit Holder	9
58	2 604 610 038	Impact Spring	49	115	2 912 301 118	Screw {2}	89
62	2 600 923 006	Bearing Assembly	56	116	2 916 640 003	Retaining Ring	89
67	2 606 445 010	Drive Coupling	40	118	2 605 510 146	Insert Bracket	9
70	2 606 319 085	Geared Wheel	34	119	2 601 310 009	Suspension Loop	9
72	2 600 322 051	Striker	44	120	2 603 100 056	Rubber Buffer	9
79	2 605 806 412	Impact Housing	73	753	2 607 224 231	Multi-Volt Charger	18
80	2 605 801 018	Bushing	51	791	2 610 910 400	Battery Pack 9.6V	18
				797	2 601 398 013	Strap	9