



Pos.	Part Number	Description {Qty}	F/C	Pos.	Part Number	Description {Qty}	F/C
1	2 610 905 323	Housing Assembly	71	30	2 610 038 610	Cable 50mm	10
2	2 610 352 766	Field 120V	22	31	2 610 038 852	Cable 50mm {2}	10
3	2 610 352 765	Armature 120V	AW	35	2 610 350 103	Rubber Pin {2}	66
4	2 610 910 115	Switch On/Off	15	37	2 610 352 751	Fan	23
5	2 610 352 776	Cord 120V 18/2	11	38	2 610 902 931	Vibration Foot {2}	80
5/1	2 610 352 788	Terminal	10	39	2 610 902 933	Base Plate	88
5/2	2 610 318 744	Terminal	10	41	2 610 902 932	Clamp {2}	64
6	2 610 313 327	Strain Relief	11	43	2 610 042 699	Ball Bearing	56
13	2 610 351 861	Ball Bearing	61	49	2 610 326 578	Screw {3}	89
14	2 610 352 770	Ball Bearing	60	50	2 610 352 771	Screw {4}	89
16	2 610 320 548	Brush Holder {2}	25	54	2 610 352 839	Clamping Lever {2}	80
18	2 610 352 806	Screw {2}	89	810	2 610 321 617	Brush Set	26
20	2 610 018 632	Retaining Ring	89	840	2 610 350 121	Backing Pad	88
29	2 610 352 763	Dust Cover	9				

+ = Not Illustrated * = As Required F/C = Failure Code AW = Refer to AW Labor Time Chart